



The SenzTx is a compact and robust O₂ transmitter that utilises zirconia or electrochemical technology to give a reliable measurement of oxygen concentration.

The zirconia sensor offers fast response time and a long service life with virtually no drift, whilst the electrochemical sensor allows measurement in background gases containing hydrocarbons.

The minimum output range of 0 to 10ppm is ideal for nitrogen generation or glove box monitoring. The SenzTx transmitter can also be supplied with measuring ranges up to 0 to 100% O_2 for oxygen concentrators.

The flexibility is further enhanced by process connection multiple output options.

Applications

- » Gas generation (oxygen / nitrogen)
- » Additive manufacturing
- » Glove box purge and leak detection
- » Industrial gas applications

Plug&Play Technology

Features

- » Zirconia or electrochemical sensor technology options
- Measurement range:
 0 to 10ppm up to 0 to 100% O₂
- » Analogue output: 4 to 20mA
- » Modbus 485
- » 24VDC power supply
- » M12 electrical connection
- » Process connection: KF40 Flange or Flowthrough base
- » Combined Sensor & Electronics allows for ease of integration.
- » Fast reponse from ambient air to low PPM oxygen measurement





Oxygen Transmitter

Proven sensor technology

With a choice of either zirconia or electrochemical sensor technology the SenzTx offers reliability, accuracy and flexibility. Both technologies have a broad measurement capability allowing the user to measure from selected ranges from 1ppm to 100% oxygen.

Zirconia sensor

The Ntron zirconia oxygen sensor is a nondepleting zirconia solid electrolyte sensor. A small capillary on the sensor controls the diffusion of oxygen into the sensor. When heated to over 400°C oxygen is electronically reduced causing current flow through the zirconia electrolyte. Zirconiumoxide allows the movement of oxygen ions through the substrate from a high to a low concentration. The measurement of oxygen is determined by the current flowing through the electrodes. The zirconia sensor has an unlimited shelf life without the loss of calibration and has an expected life of three to five years. The zirconia sensor is not position sensitive and has low cross sensitivity to other gases and does not dry out.

Low maintenance and cost of ownership

Due to the highly stable nature of the sensor, a calibration interval of once per year is required, allowing for significant cost savings. The construction of our zirconia oxygen sensor means that only 100 mL/ min of sample gas is required, providing application flexibility and further potential cost savings.

Fast response time

Zirconia oxygen sensor have a fast recovery from ambient air to low PPM oxygen. The response time (T90) to step changes of concentration <10 seconds..

TXi Communication & Diagnostics terminal

The TXi calibration makes set-up, calibration and diagnostics easy. Simply connect this unit in series with the SenzTx with the cable provided and perform the desired task without the need to look at the control panel which may be far away.

Electrochemical sensor

The key elements of the electrochemical sensors are a membrane, cathode, anode, electrolyte and measurement circuit. The sensing membrane (covering the cathode) is made of PTFE and is mounted over a metal perforated electrode. The space between the membrane and the electrode is filled either with an aqueous alkaline or an acid electrolyte. In normal operation, all portions of the anode and cathode are immersed in the electrolyte. As oxygen diffuses through the membrane into the electrolyte it causes a reaction between the cathode and anode generating an EMF. This current is proportional to the amount of oxygen present in the sample gas. In the absence of oxygen there is no output from the electrochemical sensor, meaning only one calibration is required.

Sensor contruction

The main body of the sensor is fabricated from high density PVDF. The supporting ring at the face of the sensor is constructed of stainless steel. This results in an oxygen sensor that is chemically resistant to most sampling atmospheres and can be used with trace solvents and hydrocarbons present in the sample gas, unlike zirconia (due to the high temperature of the sensor).


Installation flexibility

The compact SenzTx oxygen transmitter with its inbuilt microprocessor, is designed for OEM applications with minimal use input. With the flow through sensor with orifice option, the sensor can handle up to 2 bar g and provide the correct flow through the sensor. This eliminates the need for external flow control.



SenzTx

Oxygen Transmitter




Notes: 1. Cable cores that are not used must be insulated / heat-shrinked.

Technical Specifications

Oxygen Transmitter

SenzTx

Performance				
Transmitter Model	SenzTx			
Measurement technology	Zirconia (ZR)	Electrochemical (EC)		
Measurement range*	0 to 1000ppm / 0 to 1% / 0 to 25% / 0 to 96% / 0 to 100%**	0 to 1000ppm / 0 to 25%		
Output resolution (for %)	0.0	0.01%		
Output resolution (for ppm)	1ppm			
Accuracy	+/-2% of reading (or 2ppm O2) @ c	+/-2% of reading (or 2ppm O2) @ calibrated temperature and pressure		
Response time (T90)	<10 seconds @ 25°C	<10 seconds @ 25°C (within selected range)		
LDL (Sensitivity)	0.01% (when measuring %) / 1ppm (when measuring ppm)			
Temperature range	-20°C to +50°C	0°C to +45°C		
Pressure range	900 to 1100 mBar _{abs}			
Linearity	+/- 2% of reading			
Life expectation	3-5 years	1 year		
Humidity	0-95% RH no	0-95% RH non-condensing		
Shelf life	No shelf life			
Electrical Input / Output				
Power supply	24VDC +/- 10%			
Power consumption	Maximum 50mA @ 24VDC			
Signal output	4-20mA			
Digital communications	RS485 Modbus protocol. Multiple devices can be connected in a linear series			
Electrical interface	M12 × 1.5	M12 x 1.5 connection		
Cable length	1 metre (as standard)	1 metre (as standard) / 3 metres / 10 metres		
Mechanical Specification	15			
Dimensions	47mm Diameter x 120mm to 140	47mm Diameter x 120mm to 140mm depending on connection type		
Weight	0.26	0.260kg		
Wetted materials	Aluminium,	Aluminium, PTFE, Viton		
Process connection	Flowthrough base with 1/8" NP	Flowthrough base with 1/8" NPT (parallel thread) / KF40 Flange		
Ingress protection	IP	IP 66		
Housing material	Anodised	Anodised aluminium		
Certification				
Complies with EMC Directive 2004	4 / 108 / EC. UL/ETL Certification Number: UL-6	1010-1		



* Outputs can be factory set to other ranges. Please see order code sheet for details.

** Exact range - 0 to 99.5%



 Ntron Gas Measurement Unit 2, Mullaghboy Industrial Park, Navan, Co. Meath, C15 XD61, Ireland

 Phone: +353 (0)46 907 1333
 Fax: +353 (0)46 907 1331
 Email: sales@ntron.com
 www.ntron.com

 Ntron Gas Measurement adopts a continuous development programme which sometimes necessitates specification changes without notice.
 Issue No. STX01 V2 EN 0720
 © 2020 Ntron Ltd.

SenzTx

Oxygen Transmitter

Ordering information

Model	Range (O ₂)	Sensor Type	Process Connection	Part No
SenzTx 101	0 - 25%	Zirconia: OC-71	Flowthrough	02-662
SenzTx 101	0 - 25%	Zirconia: OC-71	Flowthrough w/ Orifice	05-139
SenzTx 111	0 - 25%	Zirconia: OC-71	KF-40 Flange	04-068
SenzTx 201	0 - 25%	Electrochemical: OC-61	Flowthrough	04-072
SenzTx 201	0 - 25%	Electrochemical: OC-61	Flowthrough w/ Orifice	05-142
SenzTx 211	0 - 25%	Electrochemical: OC-61	KF-40 Flange	03-754
SenzTx 201	0 - 25%	Optical: Luminox	Flowthrough	06-414
SenzTx 201	0 - 25%	Optical: Luminox	Flowthrough w/ Orifice	06-415
SenzTx 211	0 - 25%	Optical: Luminox	KF-40 Flange	06-227
SenzTx 100	0 - 1000 PPM	Zirconia: OC-70	Flowthrough	02-661
SenzTx 100	0 - 1000 PPM	Zirconia: OC-70	Flowthrough w/ Orifice	05-138
SenzTx 110	0 - 1000 PPM	Zirconia: OC-70	KF-40 Flange	04-067
SenzTx 200	0 - 1000 PPM	Electrochemical: OC-62	Flowthrough	04-071
SenzTx 200	0 - 1000 PPM	Electrochemical: OC-62	Flowthrough w/ Orifice	05-141
SenzTx 210	0 - 1000 PPM	Electrochemical: OC-62	KF-40 Flange	03-753
SenzTx 200	0 - 1000 PPM	Optical: Luminox	Flowthrough	06-202
SenzTx 200	0 - 1000 PPM	Optical: Luminox	Flowthrough w/ Orifice	06-416
SenzTx 210	0 - 1000 PPM	Optical: Luminox	KF-40 Flnage	06-147
SenzTx 102	0 - 96%	Zirconia: OC-72	Flowthrough	02-663
SenzTx 102	0 - 96%	Zirconia: OC-72	Flowthrough w/ Orifice	05-140
SenzTx 112	0 - 96%	Zirconia: OC-72	KF-40 Flange	04-069
SenzTx 102	0 - 100%	Zirconia: OC-72	Flowthrough	06-456
SenzTx 102	0 - 100%	Zirconia: OC-72	Flowthrough w/ Orifice	06-457
SenzTx 102	0 - 100%	Zirconia: OC-72	KF-40 Flange	06-458



 Ntron Gas Measurement
 Unit 2, Mullaghboy Industrial Park, Navan, Co. Meath, C15 XD61, Ireland

 Phone: +353 (0)46 907 1333
 Fax: +353 (0)46 907 1331
 Email: sales@ntron.com
 www.ntron.com

 Ntron Gas Measurement adopts a continuous development programme which sometimes necessitates specification changes without notice.
 Issue No. STX01_V2_EN_0720
 © 2020 Ntron Ltd.